

Step #5

SEARCH, MOVIES, SERIES


In LIVE TV, FULL SCREEN press “OK” button.





Down button twice to “search” tab under options.



Move cursor into search bar and enter word or phrase. In the example below we used “dateline”



Down button to all “channels”, “programs”, “recordings” “movies” and “series” that contain search phrase. In this example we used “dateline”.



In lieu of search, user can go directly to Movies and Series tab, press “OK” and go to screens below and see Movie and Series offering by category. User may use search glass (blue at top of categories) to search within movies or series.

